

# SLIM SPOT 36X1W RGBA USER MANUAL

Thanks for choosing the LED SLIM SPOT light. This is the innovative LED application for professional lightings. Since the RGBW four colors ultra bright LED lamps, the unit can combine more than billions of color effects. This item can be used for the buildings, Studio center, theatre, entertainment stage, dancing halls, clubs etc..

## **Technical Specifications:**

- LED: 36 x 1W / RGBA (R:9, G:9, B: 9, A: 9)  
Beam angle: 30 degree
- Power: 50W
- Voltage: AC100V-240V. 60Hz-50Hz
- Built-in scenes
- DMX control: 6ch (Dimmer, R,G, B, A, Color Macro/Scroll & Strobe)
- Master and slave control
- Size: 23\*23\*7.6CM
- Weight: 1.8kgs

## **Operation Instructions (LED DISPLAY) :**

On LED Display, please NOTE:

**When the digit flash, that means you can select this mode and via UP/DOWN to choose. After making your choice, press SET UP for confirmation of your setting everytime!!**

### **STEP 1: C000**

Press MODE button into this window----STATIC COLOR SELECTION.

**C100** RED: 00-99 beam level adjustable.

**C200** GREEN: 00-99 beam level adjustable.

**C300** BLUE: 00-99 beam level adjustable.

**C400** AMBER: 00-99 beam level adjustable

**CF00** STROBE:00-99 speed adjustable.

### **STEP 2: JU00**

Press MODE button into this window----COLOR JUMP SELECTION.

**JU00** RGBA 15 colors: 00-99 speed adjustable.

**JF00** STROBE: 00-99 speed adjustable.

### STEP 3: FA00

Press MODE button into this window----COLOR FADE SELECTION.

FA00 RGBA: 00-99 speed adjustable.

FF00 STROBE: 00-99 speed adjustable.

### STEP 4: SLAV

Press MODE button into this window----SLAVE SETTING.

### STEP 5: A001

Press MODE button into this window----DMX ADDRESS SETTING.

Connect with the standard DMX controller to fulfill the following operation and function:

### **DMX channel assignment and function:**

CH1	CH2	CH3	CH4	CH5	CH6	CH7
<b>Dimmer (0-255)</b>	<b>Strobe (0-255)</b>	<b>RED (0-255)</b>	<b>GREEN (0-255)</b>	<b>BLUE (0-255)</b>	<b>AMBER (0-255)</b>	<b>0-4: Blackout</b>
						<b>5-80: Color Micro</b>
						<b>81-150: Color Jump</b>
						<b>151-255: Color Fade</b>