

LED PAR64 TRI-18 USER MANUAL

Thanks for choosing the LED PAR64 TRI-18 light. This is the innovative LED application for professional lightings. Since the RGB ultra bright LED lamps, the unit can combine more than 16.7 million soft color effects. It meets to use for the entertainment stage, dancing halls, clubs etc..

Technical Specifications:

- LED: 18 x 3W RGB (3 IN 1 MULTI LED)
- Power: 60W
- Voltage: AC110V-250V. 60Hz-50Hz
- Built-in scenes & Sound active
- DMX control: 6ch (Dimmer, R,G,B, Color Macro/Scroll & Strobe)
- Master and slave control
- Size: 31*23*22CM
- Weight: 2.8kgs

Operation Instructions (LED DISPLAY) :

On LED Display, please NOTE:

When the digit flash, that means you can select this mode and via UP/DOWN to choose. After making your choice, press SET UP for confirmation of your setting everytime!!

STEP 1: C000

Press MODE button into this window----STATIC COLOR SELECTION.

C100 RED: 00-99 beam level adjustable.

C200 GREEN: 00-99 beam level adjustable.

C300 BLUE: 00-99 beam level adjustable.

CF00 STROBE:00-99 speed adjustable.

STEP 2: J000

Press MODE button into this window----COLOR JUMP SELECTION.

J300 RGB: 00-99 speed adjustable.

J700 7COLOR: 00-99 speed adjustable.

JF00 STROBE: 00-99 speed adjustable.

STEP 3: F000

Press MODE button into this window----COLOR FADE SELECTION.

F300 RGB: 00-99 speed adjustable.

F7007COLOR: 00-99 speed adjustable.

FF00STROBE: 00-99 speed adjustable.

STEP 4: S000

Press MODE button into this window----SOUND ACTIVE.

S300 RGB: 00-99 sound sensitivity adjustable.

S7007COLOR: 00-99 sound sensitivity adjustable.

SF00STROBE: 00-99 speed adjustable.

STEP 5: Slav

Press MODE button into this window----SLAVE SETTING.

STEP 5: Addr

Press MODE button into this window----DMX ADDRESS SETTING.

Connect with the standard DMX controller to fulfill the following operation and function:

DMX channel assignment and function:

CH1	CH2	CH3	CH4	CH5	CH6
Master dimmer (0-255)	RED (0-255)	GREEN (0-255)	BLUE (0-255)	0-4: Blackout	STROBE (0-255)
				5-84: Color Micro	
				85-169: Color Jump	
				170-255:Color Fade	