

SLIM SPOT TRI-18 USER MANUAL

Thanks for choosing the SLIM SPOT TRI-18 light. This is the innovative LED application for professional lightings. Since the RGB ultra bright LED lamps, the unit can combine more than 16.7 million soft color effects. It meets to use for the entertainment stage, dancing halls, clubs etc..

Technical Specifications:

- LED: 18 x 3W RGB (3 IN 1 MULTI LED)
- Power: 60W
- Voltage: AC110V-250V, 60Hz-50Hz
- Built-in scenes & Sound active
- DMX control: 3ch/6ch
- Master and slave control
- Size: 23*23*8.6CM
- Weight: 2.8kgs

Operation Instructions (LED DISPLAY) :

On LED Display, please NOTE:

When the digit flash, that means you can select this mode and via UP/DOWN to choose. After making your choice, press SET UP for confirmation of your setting everytime!!

STEP 1: C000

Press MODE button into this window----STATIC COLOR SELECTION

C100 RED: 00-99 beam level adjustable.

C200 GREEN: 00-99 beam level adjustable

C300 BLUE: 00-99 beam level adjustable

CF00 STROBE: 00-99 speed adjustable.

STEP 2: 0000

Press MODE button into this window----COLOR JUMP SELECTION.

0300 RGB: 00-99 speed adjustable.

0700 7COLOR: 00-99 speed adjustable.

0F00 STROBE: 00-99 speed adjustable.

STEP 3: F000

Press MODE button into this window----COLOR FADE SELECTION.

F300 RGB: 00-99 speed adjustable.

F700 7COLOR: 00-99 speed adjustable.

FF00 STROBE: 00-99 speed adjustable.

STEP 4: S000

Press MODE button into this window---SOUND ACTIVE.

S300 RGB: 00-99 sound sensitivity adjustable.

S700 7COLOR: 00-99 sound sensitivity adjustable.

SF00 STROBE: 00-99 speed adjustable.

STEP 5: Slav

Press MODE button into this window---SLAVE SETTING

STEP 5: Addr

Press MODE button into this window---DMX ADDRESS SETTING

Connect with the standard DMX controller to fulfill the following operation and function:

DMX channel assignment and function:

3channel mode:

| CH1 | CH2 | CH3 |
|-------------|---------------|--------------|
| RED (0-255) | Green (0-255) | Blue (0-255) |

6channel mode:

| CH1 | CH2 | CH3 | CH4 | CH5 | CH6 |
|--------------------------|----------------|------------------|-----------------|---------------------|-------------------|
| Master dimmer (0-255) | RED (0-255) | GREEN (0-255) | BLUE (0-255) | 0-4: Blackout | STROBE (0-255) |
| | | | | 5-84: Color Micro | |
| | | | | 85-169: Color Jump | |
| | | | | 170-255: Color Fade | |