


1. Function key:



- A. Function key
- B. Up
- C. Down
- D. Enter
- E. LED display



There are 8 function effects after enter A key, first two word show function display, other two word show speed, address, press B or C amend data, and press D key means confirmation the function you choose.

2. Led display

No.	Display	Description
1	A001	5CH address, (001-512) B. C adjust address
2	H001	9CH address, (001-512) B. C adjust address
3	CC00	Multi color jump, (00-99) B. C adjust speed
4	CP00	Multi color changing, (00-99) B. C adjust speed
5	DE00	Multi color pulse, (00-99) B. C adjust speed
6	BEB1	Multi color sound active effect -1
7	R255	RED, (000-255) B. C key change color
8	G255	Green, (000-255) B. C key change color
9	B255	Blue, (000-255) B. C key change color
10	U255	Write, (000-255) B. C key change color
11	ID 00	DMX512 ID, (00-51), ID=0 close ID B, C key can amend DMX 512 after enter D key, when operat ID, it needs 5seconds to open light
12	U90	

13	Ir O/F	On/off wireless remote
14	FROM	Slave mode

3. Remote display

No.	The remote display	LED display	Description
1	ON/OFF		Power on/power off
2	Quit		Controller and remote mode selection
3	Mode1	cc0	Multi color jump change, (0-9) + and - adjust speed
		cp0	Multi color changing, (0-9) + and - adjust speed
		de0	Multi color pulse, (0-9) + and - adjust speed
4	Mode2	C00	Select color, (0-14) + and - adjust color
5	Mode3	Eb1	Sound active with color changing-1
6	Mode4		Strobe
			+ - adjust speed

4. DMX512 5CH

No.	Display	Description
CH 1	Red dimmer	R dimmer from dark to brilliant
CH 2	Green dimmer	G dimmer from dark to brilliant
CH 3	Blue dimmer	B dimmer from dark to brilliant
CH 4	Write dimmer	W dimmer from dark to brilliant

No.	Display	Description
CH 5	DMX512 ID	ID 0 or (0--4) close ID
		ID 1 5--9
		ID 2 10--14
		ID 3 15--19
		ID 4 20--24
	
		ID 51 255
		Control the 50pcs light under the DMX address

5. DMX512 9CH

No.	Display	Description
CH 1	Dimmer	R. G. B. W from dark to brilliant
CH 2	Strobe	R. G. B. W from slow to fast
CH 3	Function	0--50: DMX 9CH; 51--100: Jump change; 101--150: change; 151--200: pulse change; 201--255: sound control;
CH 4	Speed	from slow to fast
CH 5	Red	R dimmer from dark to brilliant
CH 6	Green	G dimmer from dark to brilliant
CH 7	Blue	B dimmer from dark to brilliant
CH 8	Write	W dimmer from dark to brilliant
CH 9	DMX512 ID	ID 0 or (0--4) close ID
		ID 1 5--9
		ID 2 10--14

No.	Display	Description
		ID 3 15--19
		ID 4 20--24
		ID 51 255
		Control the 50pcs light under the DMX address

6. Technical specifications

Voltage:	AC 100 -240V 50/60Hz
Light Source:	3x10W 4 in 1 LEDs
Lamp bead life:	50,000 hours life expectancy
DMX Channels:	5 or 9CH
DMX Connectors:	3-pin XLR
Strobe Rate:	0 to 17 Hz
Beam Angle:	16°
Field Angle:	30°
Illuminance:	1,066 lux @ 2 m
Weight:	0.8 kg
Size:	110 x 110 x 135 mm
Included Controllers:	IRC